



40123



1



2




3




4






2x


1





1x

2




1x



2x



3




4




4





5






6




6





7






8



9






1x



4x

# 10




2x




1x



# 11








12



13





1x



2x




2x



1x

# 14



1x




1x




1x

# 15







2x



1x

# 16





1x




1x



1x

# 17





1x



2x

# 18



1x



1x



1x

# 19





1x



1x

# 20



1x



1x

# 21





2x



1x

# 22



2x

# 23





1x



1x



1x



1x

# 24

1



2







4x

25





2x



2x

# 26



4x


# 27






1x

1



2x

2




1x



2x

3



2x



2x

4





1x



2x

5



2x

6



20

28





1x



1x



2x

# 29



1x



1x




1x



2x

# 30





1x



1x



1x

# 31



1



2





1x





1x



1x

# 32





1x




1x



1x

# 33




1




2







# 34





1x

1



4x



1x

2





1x



1x

3



1x

4







2x



2x

5



1x



1x



1x

6





1x



1x



1x

7



2x



1x

8

1



2







Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



LEGO and the LEGO logo are trademarks of the/son des marques  
de commerce du/son marcas registradas de LEGO Group.  
©2015 The LEGO Group. 6123836 / 6123837