



40181

EXCLUSIVE
only at
ToysRUs

EN EXCLUSIVITÉ
uniquement chez
ToysRUs







1x

1x

1



2x

2






3x



1x

3



1x




1x



3x

4





8x




1x



1x

5




1x



4x

6





2x




1x




2x

7

1



2





2x



2x

8






3x



2x

9



1x



1x



3x



1x

10

1



2





2x



1x



2x

11



2x




1x



2x

12





1x



1x



2x

13



1x



3x



1x

14





1x



2x



1x

15

1



2



1x



1x

16





1x




3x



2x

17



2x




1x



2x

18





3x




6x



1x

19





1x



2x

20





1x



1x



1x

21





1x




1x



1x

22





2x




2x



2x

23





1x



1x



1x

24





2x



1x



1x



4x



1x



1x



1x



1x



3x

1



2




3



4



5



6



7





1x



2x



2x



1x



2x



4x

1



2



3



4



5



6







Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



40180



40181



40182



40183

