



40180

EXCLUSIVE
only at
ToysRUs

EN EXCLUSIVITÉ
uniquement chez
ToysRUs







1x

1x

1




1x



3x

2






2x



2x

3



8x




1x



2x


4





3x

5




2x



2x

6





2x




2x

7

1



2





1x




2x



2x

8





4x



4x

9







2x



2x

10



8



2x




1x



2x


11






6x

12




3x




8x

13



4x





2x





2x



2x

14




1x




2x

15





2x



1x



1x




1x



1x

16



1



2




3





2x

17




4x



2x

18





3x



2x

19




3x



2x


20





3x

21



2x



2x

22






1x



2x

23





2x



2x

24



1x



2x

25





1x




1x



1x

26

1



2





2x




2x

27



2x





1x



1x



1x

28



1



2






1x



4x

29





1x



1x



1x



1x



1x



1x

1



2



3



30





1x



2x



2x



1x



1x



1x



4x

1



2



3




4



5



6





1x



1x



1x



2x



2x



1x



4x




1x


1



2




3




4




5



6







Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



40180



40181



40182



40183

