



Mixels

41570

SKRUBZ




 LEGO.com

6157132


1




2




3




4




5




6




7




8




9




10




11




12




13





14




15




16




17







18




1





2



19




20







21





22




23





24







25



26




27






1




2



3




4



5








2x
4619513



1x
6102828



1x
6141594



2x
6141593



1x
4594685



2x
609121



1x
302301



2x
6046384



2x
4567449



2x
4249506



3x
302101



3x
371001



4x
6046905



1x
4119013



2x
4547489



1x
6142859



1x
6060734



4x
6093053



2x
6092873



2x
243201



1x
6056234



1x
292126



2x
249626



1x
6094141



2x
4141580



1x
302226



6x
3005749



2x
4541978



2x
4211373



2x
6028812



1x
4654582



2x
4515369



1x
6093058



1x
4211042



4x
4210631



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :






**SURGEO
41569**

**SKRUBZ
41570**

**TUTH
41571**

**MEDIX
MAX!**



 LEGO.com/mixels 



Mixels

SERIES
8

SKULZY
41567



AQUAD
41564



SPLASHO
41563



SKRUBZ
41570



SURGED
41569



SHARK
41566



LEWT
41568



TUTH
41571



HYDRO
41565



LEGO.com/mixels





club™



1 LEGO.com/club



2



3

