

CREATOR



40140

LEGO.com/creator


6112639 / 6112640




1




2




3




4




5




6




7




8




9






10




11



12



13



14



15

