



Mixels

41559

PALADUM




6150695


1




2




3



4




5




6




7




8





9




10




11






12





13





14




15




16




17



18




19



20




21



22






23





24







25






27





1



2




3



4



5



6





4x
6131655



4x
6004990



1x
4666449



5x
4579354



1x
6094141



2x
4504376



3x
4585493



1x
6056225



2x
6043656



2x
4211804



4x
6029948



4x
302226



2x
4211150



2x
6024604



1x
6060732



2x
4211475



1x
6093058



1x
4210892



1x
6016172



2x
6008297



1x
4611883



1x
6021783



2x
6123814



2x
6015891



4x
4211199



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



2x
4648256



1x
4569733



1x
4211186



2x
4141580



1x
449521



2x
292126



**CAMILLOT
41557**




**MIXADEL
41558**



**PALADUM
41559**

**MEDIVALS
MAX!**



LEGO.com/mixels



SERIES
7

WELCOME TO
MIXOPOLIS



PALADUM
41559



CAMILLOT
41557



TAPSY
41561



TRUMPSY
41562



KUFFS
41554



JAMZY
41560



BUSTO
41555



TIKETZ
41556



MIXADEL
41558



LEGO.com/mixels



Mixels™

WELCOME TO
MIXOPOLIS

