

LEGO

Mixels

41565

HYDRO



CN
CARTOON NETWORK


7 LEGO.com

6157117


1




2




3




4





5





6





7




8



9




10




11



12




13




14



15




16






17




18




19



20



21






22



23




24




25




26



27



28






29



30




31




32




33





34




35



36




37






1




2




3



4



5





2x
6043656



4x
302321



2x
6104016



2x
614101



2x
4578677



2x
6051038



2x
4654582



4x
6029946



4x
4540040



2x
462401



2x
4598528



3x
302226



1x
4210631



1x
6061711



1x
403224



2x
6056225



2x
4504369



4x
6020193



4x
4646861



2x
6023770



3x
302324



2x
4504369



4x
6020193



2x
6092658



2x
4155537



1x
6060729



4x
6020193



2x
4515368

Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



1x
6046384



2x
4141580



2x
4515368



3x
4556152



2x
366026



2x
292126



2x
6099448



SPLASHO
41563




AQUAD
41564



HYDRO
41565



MCFD
MAX!



LEGO.com/mixels





Mixels

SERIES
8

SKULZY
41567



AQUAD
41564



SPLASHO
41563



SKRUBZ
41570



SURGED
41569



SHARK
41566



LEWT
41568



TUTH
41571



HYDRO
41565



LEGO.com/mixels





club™

