



CREATOR

20003




LEGO BrickMaster




1



2




3




4




5






6




7







4




5




6




7




8




9




10



11










12








13





1



2



3




4



5



6




1



2




7



1




2



12

3




4



8



9





1



2



3




4




5



6




1



2




7



1




2



16


3



4




8





9



1




2




3



4



10





6x  
4273397



10x  
4224792



2x  
3005747



2x  
4121715



5x  
4521427



1x  
4211189



2x  
4211252



1x  
4143372



1x  
4140303



2x  
4185620



4x  
4189043



2x  
302226



1x  
4508453



2x  
4251161



2x  
4161332



2x  
4160869



5x  
4504392



1x  
329825



2x  
370026



1x  
4143875



2x  
4210632



2x  
4211069



2x  
4210726



5x  
4107758



2x  
371028



1x  
366628



1x  
302128



2x  
4211477



1x  
4515341



3x  
4211395



4x  
4142989



4x  
4187334



2x  
4157120



2x  
302428



15x  
302328



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

[www.lego.com/service](http://www.lego.com/service) or dial



00800 5346 5555 :



1-800-422-5346 :

